0445110771 CRI2-16 Fuel Injector Technical Data



SKU: G1W20445110771

COMMON RAIL DIESEL INJECTORS

DIESEL INJECTORS



0445110771 CRI2-16 Fuel Injector Technical Data

Content

1. 0445110771 CRI2-16 Fuel Injector Introduction	2
1.1. 0445110771 CRI2-16 Fuel Injector Basic Information	2
1.2. 0445110771 CRI2-16 Fuel Injector Common Information	2
1.3. 0445110771 CRI2-16 Fuel Injector Part Number Common Writing	2
1.4. 0445110771 CRI2-16 Fuel Injector Parameter	2
1.5. 0445110771 CRI2-16 Fuel Injector Quality Control	3
1.6. 0445110771 CRI2-16 Fuel Injector Customized Service	3
1.7. 0445110771 CRI2-16 Fuel Injector Packing List and Package Size	4
1.8. 0445110771 CRI2-16 Fuel Injector Testing Standard and Certificate	5
1.9. 0445110771 CRI2-16 Fuel Injector Warranty Instructions	6
2. 0445110771 CRI2-16 Fuel Injector Technical Support	7
2.1. 0445110771 CRI2-16 Fuel Injector Part Number Location	7
2.2. 0445110771 CRI2-16 Fuel Injector Application Scenarios	7
2.3. 0445110771 CRI2-16 Fuel Injector Installation Precautions	8
2.4. Reasons For 0445110771 CRI2-16 Fuel Injector Not Working Normally	9
2.5. Causes of 0445110771 CRI2-16 Fuel Injector Being Damaged	9
2.6. 0445110771 CRI2-16 Fuel Injector Storage Standard	10
2.7. 0445110771 CRI2-16 Fuel Injector Technical Support Obtaining Methods	10
3. 0445110771 CRI2-16 Fuel Injector Purchase and Delivery	11
3.1. 0445110771 CRI2-16 Fuel Injector Purchase Payment Term	11
3.2. 0445110771 CRI2-16 Fuel Injector Main Sales Markets	11
3.3. 0445110771 CRI2-16 Fuel Injector Declaration Requirements	11
3.4. 0445110771 CRI2-16 Fuel Injector Shipping Ways	11
3.5. 0445110771 CRI2-16 Fuel Injector Lead time	11
3.6. 0445110771 CRI2-16 Fuel Injector Logistics Time for Destination Out of China's Areas	11
3.7. 0445110771 CRI2-16 Fuel Injector Packing	12
4. Company Information	
4.1. Company Introduction	13
4.2. Contact Information	14
5. Copyright Statement	14

CR



0445110771 CRI2-16 Fuel Injector Technical Data

1. 0445110771 CRI2-16 Fuel Injector Introduction

1.1. 0445110771 CRI2-16 Fuel Injector Basic Information

Title	0445110771 Common Rail Fuel Injector China Made New			
SKU	G1W20445110771			

1.2. 0445110771 CRI2-16 Fuel Injector Common Information

1) CRI2-16 Fuel Injector Exchange Information

CRI2-16 Fuel Injector Part Number	Re-manufactured Part Number
0 445 110 771	
0 445 110 774	/

2) CRI2-16 Fuel Injector Application Information

CRI2-16 Fuel Injector Part Number	Car Model
0 445 110 771	
0 445 110 774	/

3) CRI2-16 Fuel Injector Matching Information

	Vehicle brand	Series	Car Model	Engine Model	Production date	Power KW	Horse power	Emission Standards	Manufacturer	Emissions(L)	Cylinder	Power Source V
R		/		/		/	/				/	/

1.3. 0445110771 CRI2-16 Fuel Injector Part Number Common Writing

0445110771, 0445110774, 0 445 110 771, 0 445 110 774, 0 445 110771, 0 445 110774, 0 445110771, 0 445110771, 0 445110774, 0 44511074

1.4. 0445110771 CRI2-16 Fuel Injector Parameter		
Adaptation System: Common Rail System		
CRI2-16 Fuel Injector Series: 110 Series		
Parameter Performance: CRI2-16		
Matching Accessories: Gasket F 00V C17 504		
CRI2-16 Fuel Injector Type: Electromagnetic CRI2-16 Fuel Injector		
Support System Maximum Pressure: /		
Vehicle Configuration Information: /		
CRI2-16 Fuel Injector Size: 21 cm*7 cm *6 cm		
CRI2-16 Fuel Injector Net Weight: 0.45kg		
CRI2-16 Fuel Injector Gross Weight: 0.6kg		
CRI2-16 Fuel Injector Quality: China Made New		
CRI2-16 Fuel Injector Package Size: 28 cm*7 cm *7 cm		
CRI2-16 Fuel Injector Type: Diesel CRI2-16 Fuel Injector		
CRI2-16 Fuel Injector MOQ: 4 Pieces		



1.5. 0445110771 CRI2-16 Fuel Injector Quality Control

1) CRI2-16 Fuel Injector Testing

All CRI2-16 fuel injectors are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

2) CRI2-16 Fuel Injector Assembling


For quality control during the production and installation process of CRI2-16 fuel injectors, our company strictly follows the standard product installation data and product installation steps for installation and testing, such as injector stroke test, injector solenoid valve tightening torque test, injector nozzle tightening torque test, etc.

3) CRI2-16 Fuel Injector Inspection

The factory inspection of the CRI2-16 fuel injector is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same CRI2-16 fuel injector for a total of more than three times for factory inspection, and the CRI2-16 fuel injector installation testing environment are progressed in dust-free workshop.

1.6. 0445110771 CRI2-16 Fuel Injector Customized Service

1) CRI2-16 Fuel Injector Customized Service Coverage: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, CRI2-16 fuel injector internal packaging, CRI2-16 fuel injector external packaging and labels customized, etc.



2) CRI2-16 Fuel Injector Customized Service Requirements:

- ① The purchase of customized CRI2-16 fuel injectors are not less than 10 pieces.
- ② The purchase of customized CRI2-16 fuel injector packages are no less than 1000 pieces.

When the customized products involve the need of specify logo, the OEM manufacturer is asked to provide trademark authorization and the sample of logo image file.

• Once the customized CRI2-16 fuel injector is sold, it cannot be returned or exchanged if there is no quality problems.





1.7. 0445110771 CRI2-16 Fuel Injector Packing List and Package Size

1) CRI2-16 Fuel Injector Spare Parts List

No.	1	2	3		
Image		0			
Name	CRI2-16 Fuel Injector	O-ring	Gasket F 00V C17 504		
Description	CRI2-16 fuel injector part number: 0445110771	Ensure to meet the standard of the sealing performance between the CRI2-16 fuel injector and the engine	Made of brass, used to ensure the tight fit between the CRI2-16 fuel injector cap end and the engine		
No.	4	5	6		
Image		6			
Name	Nozzle Protective Protective Cover	CRI2-16 Fuel Injector Oil Inlet Hole Protective Cover	CRI2-16 Fuel Injector Oil Return Hole Protective Cover		
Description	Protect nozzle holes from being polluted and blocked	Protect oil inlet from being polluted and blocked	Protect the solenoid valve body and terminals from being damaged by external forces		
No.	7	8	9		
Image					
Name	VCI Anti-rust Bag	Bubble Bag	CRI2-16 Fuel Injector Packing Box		
Description	Prevent CRI2-16 fuel injector from rusting	Prevent the CRI2-16 fuel injector from being damaged by external forces	Place CRI2-16 fuel injector and CRI2-16 fuel injector accessories		

Minors are forbidden to use the CRI2-16 fuel injector assembly, O-ring, gasket, nozzle protective cover, CRI2-16 fuel injector house protective cover, solenoid valve protective cover, VCI anti-rust bag, and

air bubble bag to avoid personal injury.

O-ring and gasket are disposable installation accessories, and need to be replaced for

re-installation.


The nozzle protective cover, the CRI2-16 fuel injector house protective cover, and the solenoid valve protective cover are recyclable accessories that can be reused.

VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.



The CRI2-16 fuel injector and the installation parts should be coated with appropriate sealing oil during installation.

2) CRI2-16 Fuel Injector Box Size



Pic No.1

No.	Name	CRI2-16 Fuel Injector Package Size (cm)
1 CR	CRI2-16 Fuel Injector Box	28*7*7

1.8. 0445110771 CRI2-16 Fuel Injector Testing Standard and Certificate

We can provide the factory quality inspection test report of each CRI2-16 fuel injector to ensure that each CRI2-16 fuel injector delivered meets the engine performance indicators.

RINJECTORS CRINJECTORS CRINJECTORS

CRINJECTORS

Website : www.cr

Website : <u>www.crinjectors.com</u>

© 2024 Shenzhen Shumatt Technology Co., Ltd

ECTORS 5 / 15

RINJECTORS



	BOTEN		测试	服告	4.05.2019	10:42:09
$P \ge 0$	承伸企业:					12
CTORS CF	电话:		284	t;		
	倚耳:		403	8人:		
	安户教授:					
	tið:		137.8	自单位:		
ORS CF	倚阗:		8F	9姓名:		
	放野 脱洼:					
	如件名称:	酸油菜				
ORS CF	型号-零件号:	10				
	Mark:					
	95 000000000		检测	結果		- 31
FORS CF	101809: (096000-6511			and the set	
	LEAR TEST:	略年6年3年4日 3.6	448648	REEK OF	100年114 20月11日	~
	Rade:	37	+	357	41+216	1
	WARM	3.0	147 D±165	0		
	Har:	2013	218 5±14.4	0	····· <u>b</u> ·····	V
S CI	n.:	28.4	34.6 ± 8.5	0	····· b·····	4
	U.;	141	15,9±4.8			1
	VE:	4.7	4.5 ±1.8	e 9		*
CTORS CI						
	(let [let] le	to lead test	nic _ dri _ do	法规控制制		

Pic No.2

1.9. 0445110771 CRI2-16 Fuel Injector Warranty Instructions

1) Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the CRI2-16 fuel injector inspection equipment as evidence to feed back to the salesman when the CRI2-16 fuel injector is abnormal during using. Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. Oil leakage etc.

2) CRI2-16 Fuel Injector Warranty Coverage

Within 15 days after customer receives the 0445110771 CRI2-16 fuel injector, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 0445110771 CRI2-16 fuel injector has performance problems during the warranty period (3 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the CRI2-16 fuel injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

A Tips: For products not covered by warranty, our company can provide paid maintenance services. For

products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

3) CRI2-16 Fuel Injector Out of Warranty Coverage



1) The warranty period has expired.

② CRI2-16 fuel injector failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.

③ Customer disassembles or repairs the CRI2-16 fuel injector personally resulting in damage to the CRI2-16 fuel injector.

④ CRI2-16 Fuel injector damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).

⑤ CRI2-16 fuel injector failure or CRI2-16 fuel injector damage caused by non-CRI2-16 fuel injector design, technology, manufacturing, quality and other issues.

(6) CRI2-16 fuel injector failure due to system pressure exceeding system approved pressure.

⑦ CRI2-16 fuel injector failure caused by system voltage exceeding approved voltage.

8 CRI2-16 fuel injector failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.

(9) CRI2-16 fuel injector failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).

(1) CRI2-16 fuel injector failure caused by not following the installation angle specified in the vehicle engine maintenance manual.

11 CRI2-16 fuell injector failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.

12 CRI2-16 fuel injector failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.

13 CRI2-16 fuel injector failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.

14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the CRI2-16 fuel injector connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

2. 0445110771 CRI2-16 Fuel Injector Technical Support

2.1. 0445110771 CRI2-16 Fuel Injector Part Number Location

E.g.: See the CRI2-16 fuel injector part number as follows:



Pic No.3

No.	Name
Α	brand, logo, part number, series number
B IORS C	nozzle part number

2.2. 0445110771 CRI2-16 Fuel Injector Application Scenarios


Common rail system is an oil supply method refers to the Fuel oil from the fuel tank sucked out by the

Website : www.crinjectors.com © 2024 Shenzhen Shumatt Technology Co., Ltd

7 / 15



gear pump through the oil-water separator and the gear pump to Fuel fine filter, high-pressure pump, common rail pipe, and CRI2-16 fuel injector, all together with the closed-loop fuel supply system composed of sensors and ECU that completely separates the generation of injector pressure and the injector process from each other.



				Pic No. 4	1		
No. Name No.			Name	No.	Name	No.	Name
1	Tank	Tank 5 Com Pressu		9	Engine Crankshaft Sensor	А	High Pressure Oil Circuit
2	Fuel Filter	6	Common Rail Pipe	10	Camshaft Sensor	В	Low Pressure Oil Circuit
3	High-Pressure Pump	7	CRI2-16 Fuel Injector	11	ECU Electronic Control Unit	/	
4 Fuel Gear Pump		8	Accelerator Pedal	1		/	

2.3. 0445110771 CRI2-16 Fuel Injector Installation Precautions

- 1) The replacement of the CRI2-16 fuel injector must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.
- 2) Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the CRI2-16 fuel injector, the fitting clearance of the CRI2-16 fuel injector connection, the installation angle and tightening torque of the CRI2-16 fuel injector, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the CRI2-16 fuel injector.
- 3) When installing the CRI2-16 fuel injector on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the CRI2-16 fuel injector, and ensure that there is no dust, carbon deposits, water, rust spots, etc.
- 4) Before installing, check whether the CRI2-16 fuel injector nozzle gasket has been replaced and installed on the CRI2-16 Fuel injector.
- 5) When installing the CRI2-16 fuel injector, apply lubricant between the CRI2-16 fuel injector, fuel nozzle sealing gasket and O-ring.
- 6) Failure to replace the gasket with a new one may result in: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious



damage to the CRI2-16 fuel injector and nozzle to break and cause damage to the engine.

- 7) When installing the CRI2-16 fuel injector on the engine, please carefully check the components related to the installation of the CRI2-16 fuel injector, such as the CRI2-16 fuel injector pressure plate, sCRI2-16ew, CRI2-16 fuel injector rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.
- 8) It is forbidden to operate the bare CRI2-16 fuel injector for a long time in an environment with serious dust pollution and corrosion to iron products.
- 9) It is forbidden to operate the bare CRI2-16 fuel injector for a long time in a strong magnetic field environment.

2.4. Reasons For 0445110771 CRI2-16 Fuel Injector Not Working Normally

- 1) There is air in the oil circuit of the engine fuel system.
- 2) Vehicle oil pump oil supply system is not normal.
- 3) Engine common rail system oil leakage or pressure limiting valve is damaged.
- 4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the CRI2-16 fuel injector of the vehicle.
- 5) The long-term placement of the CRI2-16 fuel injector causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

Before installing, carefully check whether other components in the common rail system except the CRI2-16 Fuel injector are damaged so as to prevent the CRI2-16 fuel injector from not working properly after being replaced.

2.5. Causes of 0445110771 CRI2-16 Fuel Injector Being Damaged

- 1) Failure to operate correctly according to the engine maintenance manual during disassembly and assembly resulted in damage to the CRI2-16 fuel injector.
- 2) The fuel used for the vehicle does not meet the standard, causing damage to the CRI2-16 fuel injector, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- 3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. All above reasons can cause damage to the CRI2-16 fuel injector.
- 4) The abrasion of the oil pump produces iron powder and aluminum powder enter the CRI2-16 Fuel injector and cause damage to the CRI2-16 fuel injector.
- 5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the CRI2-16 fuel injector and causing damage to the CRI2-16 fuel injector.
- 6) The CRI2-16 fuel injector is damaged due to replacement or adjustment of the relevant parts of the CRI2-16 fuel injector. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the CRI2-16 fuel injector fails to

9 / 15



meet the original standard.

- 7) The engine is overheated and overloaded for a long time working results in damage to the CRI2-16 fuel injector.
- 8) The CRI2-16 fuel injector will be damaged naturally at the end of its working life.
- 9) The CRI2-16 fuel injector is magnetized (CRI2-16 fuel injector parts' magnetic exceeded) causing the CRI2-16 fuel injector to not work properly.

Before replacing the CRI2-16 fuel injector, please check the engine parts carefully according to the engine maintenance manual to avoid the CRI2-16 fuel injector being damaged again after replacement.

2.6. 0445110771 CRI2-16 Fuel Injector Storage Standard

1) Choose a Suitable Storage Place

The warehouse and cargo yard where the CRI2-16 fuel injector is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkali, salts and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

2) Strict Requirements of Warehousing

Strict inspections should be carried out when the CRI2-16 fuel injectors are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged CRI2-16 fuel injectors must be protected from damage.

3) Keep The Warehouse Dry And Preventing Moisture

The relative humidity is usually below 70% for the CRI2-16 fuel injectors placed in the room, and the corrosion of the CRI2-16 fuel injectors is significantly reduced.

CRI2-16 fuel injectors must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

4) Stack Properly

After the CRI2-16 fuel injector is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the CRI2-16 fuel injector from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse.

If the CRI2-16 fuel injector package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

It is forbidden to leave the CRI2-16 fuel injector exposed in the air for a long time.

A It is forbidden to store acids, alkalis, salts and other substances together with the CRI2-16 fuel injector.

A The unpacked CRI2-16 fuel injector must be rust-proof during secondary storage.

2.7. 0445110771 CRI2-16 Fuel Injector Technical Support Obtaining Methods



- 1) CRI2-16 Fuel Injector Technical Data: <u>https://www.crinjectors.com/download/</u>
- 2) CRI2-16 Fuel Injector Videos: <u>https://www.crinjectors.com/videos/</u>
- 3) CRI2-16 Fuel Injector Encyclopedia: <u>https://www.crinjectors.com/category/news/encyclopedia/</u>
- 4) CRI2-16 Fuel Injector Information Query Software:

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit <u>http://shumatt.com</u>to get the download and installation tutorial.

5) YouTube:

Visit <u>https://www.youtube.com/channel/UCByvYBx7VjV_mAfxh_Hu-aw</u> to get the technical videos, stay tuned for more information.

3. 0445110771 CRI2-16 Fuel Injector Purchase and Delivery

3.1. 0445110771 CRI2-16 Fuel Injector Purchase Payment Term

Payment Terms: T/T, PayPal, Alipay, WeChat

A Please contact our salesmen for specific payment information.

3.2. 0445110771 CRI2-16 Fuel Injector Main Sales Markets

CRI2-16 Fuel Injector Main Sales Markets: Asia, Europe, North America, South America, Africa etc.

3.3. 0445110771 CRI2-16 Fuel Injector Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. 0445110771 CRI2-16 Fuel Injector Shipping Ways

Destination in China Areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations Out of China's Areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. 0445110771 CRI2-16 Fuel Injector Lead time

Lead Time: Send out within 3 - 7 working days after receiving payment (Except for special products and special cases).

3.6. 0445110771 CRI2-16 Fuel Injector Logistics Time for Destination Out of China's Areas

DHL Logistics Time :

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	UK	5-7Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days

Website : www.crinjectors.com © 2024 Shenzhen Shumatt Technology Co., Ltd

11/15



Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days			1-	/

A The logistics time is for reference only and is subject to the actual arrival.

3.7. 0445110771 CRI2-16 Fuel Injector Packing


Domestic Express Packaging: Usually wrapped in waterproof scotch tape. **International Express Packaging:** Wrapped with waterproof yellow tape after wrapping the black protective film.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, also, the products can be packaged according to customers' requirements.

M The packing tray is made of plastic and can be recycled.

Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

A Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.





Name	Domestic Express	International Express	Pallet Shipping	
	Packaging	Packaging		
	Wrapped by transparent	Wrapped with yellow tape	Use pallet that meet export	
Description	tape	after wrapping black	requirements, and use white	
Description	CRINJECTORS CRINJECT	protective film	wrapping protective film to	
			wrap and bind with cable ties	

4. Company Information



4.1. Company IntroductionChinese Name: 深圳市舒马特科技有限公司English Name: Shenzhen Shumatt Technology Co., Ltd

Mob Phone/WeChat: +86-13410541523

HK Telephone: +852-67653519

Telephone: +86-755-23215133

Email: ruby@shumatt.com

Website: www.shumatt.com

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

Pic No. 5

Shenzhen Office: Exit C, Qiao Touxi Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District,



Shenzhen, China Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

9 After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: <u>1.8.0445110771 CRI2-16 Fuel Injector Warranty Instructions</u>)

4.2. Contact Information

	Name	WeChat/ WhatsApp	Email	
RS	Ruby	+86-13410541523	hison@shumatt.com	СТС

5. Copyright Statement

Without written authorization from Shenzhen Shumatt Technology Co., Ltd, no media or individual may use the content in "0445110771 CRI2-16 Fuel Injector Technical Data" for commercial purposes (including but not limited to modifying, republishing, copying, intercepting, reproducing, and disseminating any part of this work), otherwise it will be deemed as infringement. Any media or individual who commits the abovementioned infringement must immediately stop the behavior and bear full responsibility for all adverse consequences caused thereby. Shenzhen Shumatt Technology Co., Ltd. reserves the right to pursue its economic and legal responsibilities in accordance with the property rights law and relevant laws and regulations.

If there is any question, please contact us via hison@shumatt.com.

14/15