0445110943 CRI14 Fuel Injector Technical Data



DIESEL

INJECTORS

SKU: G1W20445110943

COMMON RAIL DIESEL INJECTORS



0445110943 CRI14 Fuel Injector Technical Data

Content

1. 0445110943 CRI14 Fuel Injector Introduction	2
1.1. 0445110943 CRI14 Fuel Injector Basic Information	2
1.2. 0445110943 CRI14 Fuel Injector Common Information	
1.3. 0445110943 CRI14 Fuel Injector Part Number Common Writing	2
1.4. 0445110943 CRI14 Fuel Injector Parameter	2
1.5. 0445110943 CRI14 Fuel Injector Quality Control	3
1.6. 0445110943 CRI14 Fuel Injector Customized Service	3
1.7. 0445110943 CRI14 Fuel Injector Packing List and Package Size	4
1.8. 0445110943 CRI14 Fuel Injector Testing Standard and Certificate	5
1.9. 0445110943 CRI14 Fuel Injector Warranty Instructions	NUECTORS
2. 0445110943 CRI14 Fuel Injector Technical Support	7
2.1. 0445110943 CRI14 Fuel Injector Part Number Location	7
2.2. 0445110943 CRI14 Fuel Injector Application Scenarios	8
2.3. 0445110943 CRI14 Fuel Injector Installation Precautions	
2.4. Reasons For 0445110943 CRI14 Fuel Injector Not Working Normally	9
2.5. Causes of 0445110943 CRI14 Fuel Injector Being Damaged	9
2.6. 0445110943 CRI14 Fuel Injector Storage Standard	
2.7. 0445110943 CRI14 Fuel Injector Technical Support Obtaining Methods	
3. 0445110943 CRI14 Fuel Injector Purchase and Delivery	
3.1. 0445110943 CRI14 Fuel Injector Purchase Payment Term	11
3.2. 0445110943 CRI14 Fuel Injector Main Sales Markets	11
3.3. 0445110943 CRI14 Fuel Injector Declaration Requirements	
3.4. 0445110943 CRI14 Fuel Injector Shipping Ways	
3.5. 0445110943 CRI14 Fuel Injector Lead time	11
3.6. 0445110943 CRI14 Fuel Injector Logistics Time for Destination Out of China's Area	as11
3.7. 0445110943 CRI14 Fuel Injector Packing	
4. Company Information	
4.1. Company Introduction	
4.2. Contact Information	
5. Copyright Statement	14

CR

Website : <u>www.crinjectors.com</u> © 2024 Shenzhen Shumatt Technology Co., Ltd



0445110943 CRI14 Fuel Injector Technical Data

1. 0445110943 CRI14 Fuel Injector Introduction

1.1. 0445110943 CRI14 Fuel Injector Basic Information

Title	0445110943 Common Rail Fuel Injector China Made New				
SKU	G1W20445110943	NJE			

1.2. 0445110943 CRI14 Fuel Injector Common Information

1) CRI14 Fuel Injector Exchange Information

CRI14 Fuel Injector Part Number	Re-manufactured Part Number
0445110943	//

2) CRI14 Fuel Injector Application Information

CRI14 Fuel Injector Part Number	Car Model
0445110943	

3) CRI14 Fuel Injector Matching Information

Vehicle brand	Series	Car Model	Engine Model	Production date	Power KW	Horse power	Emission Standards	Manufacturer	Emissions(L)	Cylinder	Power Source V
1		/				/	_/_		/		1

1.3. 0445110943 CRI14 Fuel Injector Part Number Common Writing 0445110943, 0 445 110 943, 0 445 110943, 0 445110943, 0445 110 943, 0445110 943, 0445 110943

1.4. 0445110943 CRI14 Fuel Injector Parameter

Adaptation System: Common Rail System			
CRI14 Fuel Injector Series: 110 Series			
Parameter Performance: CRI14			
Matching Accessories: Gasket F 00V C17 505			
CRI14 Fuel Injector Type: Electromagnetic CRI14 Fuel	l Injector		
Support System Maximum Pressure: /			
Vehicle Configuration Information: /			
CRI14 Fuel Injector Size: 21 cm*7 cm *6 cm			
CRI14 Fuel Injector Net Weight: 0.45kg			
CRI14 Fuel Injector Gross Weight: 0.6kg			
CRI14 Fuel Injector Quality: China Made New			
CRI14 Fuel Injector Package Size: 28 cm*7 cm *7 cm			
CRI14 Fuel Injector Type: Diesel CRI14 Fuel Injector			
CRI14 Fuel Injector MOQ: 4 Pieces			

Website : www.crinjectors.com © 2024 Shenzhen Shumatt Technology Co., Ltd



1.5. 0445110943 CRI14 Fuel Injector Quality Control

1) CRI14 Fuel Injector Testing

All CRI14 fuel injectors are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

2) CRI14 Fuel Injector Assembling

For quality control during the production and installation process of CRI14 fuel injectors, our company strictly follows the standard product installation data and product installation steps for installation and testing, such as injector stroke test, injector solenoid valve tightening torque test, injector nozzle tightening torque test, etc.

3) CRI14 Fuel Injector Inspection

The factory inspection of the CRI14 fuel injector is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same CRI14 fuel injector for a total of more than three times for factory inspection, and the CRI14 fuel injector installation testing environment are progressed in dust-free workshop.

1.6. 0445110943 CRI14 Fuel Injector Customized Service

1) CRI14 Fuel Injector Customized Service Coverage: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, CRI14 fuel injector internal packaging, CRI14 fuel injector external packaging and labels customized, etc.

No.	1	2	3
Image		EQ.	1000 FRANCIEL LEURS CERTIS F 1000 1000 FRANCIEL 1000 FRANC
Name	CRI14 Fuel Injector Nozzle Engraving	CRI14 Fuel Injector Solenoid Valve Lettering	CRI14 Fuel Injector Box And Label

2) CRI14 Fuel Injector Customized Service Requirements:

① The purchase of customized CRI14 fuel injectors are not less than 10 pieces.

② The purchase of customized CRI14 fuel injector packages are no less than 1000 pieces.

When the customized products involve the need of specify logo, the OEM manufacturer is asked to provide trademark authorization and the sample of logo image file.

• Once the customized CRI14 fuel injector is sold, it cannot be returned or exchanged if there is no quality problems.



1.7. 0445110943 CRI14 Fuel Injector Packing List and Package Size

1) CRI14 Fuel Injector Spare Parts List

No.	1	2	3		
Image		0			
Name	CRI14 Fuel Injector	O-ring	Gasket F 00V C17 505		
Description	CRI14 fuel injector part number: 0445110943	ector part number: Ensure to meet the standard of the sealing performance between the standard of the sealing performance between the			
No.	4	5	6		
Image		6	6		
Name	Nozzle Protective Protective Cover	CRI14 Fuel Injector Oil Inlet Hole Protective Cover	CRI14 Fuel Injector Oil Return Hole Protective Cover		
Description	Protect nozzle holes from being polluted and blocked	Protect oil inlet from being polluted and blocked	Protect the solenoid valve body and terminals from being damaged by external forces		
No.	7	8	9		
Image					
Name	VCI Anti-rust Bag	Bubble Bag	CRI14 Fuel Injector Packing Box		
Description	Prevent CRI14 fuel injector from rusting	Prevent the CRI14 fuel injector from being damaged by external forces	Place CRI14 fuel injector and CRI14 fuel injector accessories		

Minors are forbidden to use the CRI14 fuel injector assembly, O-ring, gasket, nozzle protective cover,

CRI14 fuel injector house protective cover, solenoid valve protective cover, VCI anti-rust bag, and air bubble bag to avoid personal injury.

O-ring and gasket are disposable installation accessories, and need to be replaced for

re-installation.


The nozzle protective cover, the CRI14 fuel injector house protective cover, and the solenoid valve protective cover are recyclable accessories that can be reused.

VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.



The CRI14 fuel injector and the installation parts should be coated with appropriate sealing oil during installation.

2) CRI14 Fuel Injector Box Size



Pic No.1

No.	Name	CRI14 Fuel Injector Package Size (cm)					
1 CR	CRI14 Fuel Injector Box	28*7*7					

1.8. 0445110943 CRI14 Fuel Injector Testing Standard and Certificate

We can provide the factory quality inspection test report of each CRI14 fuel injector to ensure that each CRI14 fuel injector delivered meets the engine performance indicators.

LECTORS 5 / 15

NJECTORS CR





1.9. 0445110943 CRI14 Fuel Injector Warranty Instructions

1) Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the CRI14 fuel injector inspection equipment as evidence to feed back to the salesman when the CRI14 fuel injector is abnormal during using. Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. Oil leakage etc.

2) CRI14 Fuel Injector Warranty Coverage

Within 15 days after customer receives the 0445110943 CRI14 fuel injector, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 0445110943 CRI14 fuel injector has performance problems during the warranty period (3 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the CRI14 fuel injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

Tips: For products not covered by warranty, our company can provide paid maintenance services. For

products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.



3) CRI14 Fuel Injector Out of Warranty Coverage

① The warranty period has expired.

② CRI14 fuel injector failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.

③ Customer disassembles or repairs the CRI14 fuel injector personally resulting in damage to the CRI14 fuel injector.

4 CRI14 Fuel injector damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).

⑤ CRI14 fuel injector failure or CRI14 fuel injector damage caused by non-CRI14 fuel injector design, technology, manufacturing, quality and other issues.

6 CRI14 fuel injector failure due to system pressure exceeding system approved pressure.

⑦ CRI14 fuel injector failure caused by system voltage exceeding approved voltage.

8 CRI14 fuel injector failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.

(9) CRI14 fuel injector failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).

(1) CRI14 fuel injector failure caused by not following the installation angle specified in the vehicle engine maintenance manual.

11 CRI14 fuell injector failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.

12 CRI14 fuel injector failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.

13 CRI14 fuel injector failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.

14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the CRI14 fuel injector connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

2. 0445110943 CRI14 Fuel Injector Technical Support

2.1. 0445110943 CRI14 Fuel Injector Part Number Location

E.g.: See the CRI14 fuel injector part number as follows:



Pic No.3

No.	Name	
Δ	brand, logo, part number,	
CRINJECTORS CR	series number	CRIN




nozzle part number

2.2. 0445110943 CRI14 Fuel Injector Application Scenarios

В

Common rail system is an oil supply method refers to the Fuel oil from the fuel tank sucked out by the gear pump through the oil-water separator and the gear pump to Fuel fine filter, high-pressure pump, common rail pipe, and CRI14 fuel injector, all together with the closed-loop fuel supply system composed of sensors and ECU that completely separates the generation of injector pressure and the injector process from each other.



Pic No. 4

No.	Name	No.	Name	No.	Name	No.	Name		
1 ^{CR}	Tank	5	Common Rail Pressure Sensor	9	9 Engine Crankshaft A Sensor A		High Pressure Oil Circuit		
2	Fuel Filter	6	Common Rail Pipe	10	Camshaft Sensor	В	Low Pressure Oil Circuit		
3 CR	High-Pressure Pump	7	CRI14 Fuel Injector	11	ECU Electronic Control Unit	DRS/			
4	Fuel Gear Pump	8	8 Accelerator Pedal			/			

2.3. 0445110943 CRI14 Fuel Injector Installation Precautions

- 1) The replacement of the CRI14 fuel injector must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.
- 2) Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the CRI14 fuel injector, the fitting clearance of the CRI14 fuel injector connection, the installation angle and tightening torque of the CRI14 fuel injector, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the CRI14 fuel injector.

Website : www.crinjectors.com © 2024 Shenzhen Shumatt Technology Co., Ltd



- 3) When installing the CRI14 fuel injector on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the CRI14 fuel injector, and ensure that there is no dust, carbon deposits, water, rust spots, etc.
- 4) Before installing, check whether the CRI14 fuel injector nozzle gasket has been replaced and installed on the CRI14 Fuel injector.
- 5) When installing the CRI14 fuel injector, apply lubricant between the CRI14 fuel injector, fuel nozzle sealing gasket and O-ring.
- 6) Failure to replace the gasket with a new one may result in: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the CRI14 fuel injector and nozzle to break and cause damage to the engine.
- 7) When installing the CRI14 fuel injector on the engine, please carefully check the components related to the installation of the CRI14 fuel injector, such as the CRI14 fuel injector pressure plate, sCRI14ew, CRI14 fuel injector rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.
- 8) It is forbidden to operate the bare CRI14 fuel injector for a long time in an environment with serious dust pollution and corrosion to iron products.
- 9) It is forbidden to operate the bare CRI14 fuel injector for a long time in a strong magnetic field environment.

2.4. Reasons For 0445110943 CRI14 Fuel Injector Not Working Normally

- 1) There is air in the oil circuit of the engine fuel system.
- 2) Vehicle oil pump oil supply system is not normal.
- 3) Engine common rail system oil leakage or pressure limiting valve is damaged.
- 4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the CRI14 fuel injector of the vehicle.
- 5) The long-term placement of the CRI14 fuel injector causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

A Before installing, carefully check whether other components in the common rail system except the CRI14

Fuel injector are damaged so as to prevent the CRI14 fuel injector from not working properly after being replaced.

2.5. Causes of 0445110943 CRI14 Fuel Injector Being Damaged

- 1) Failure to operate correctly according to the engine maintenance manual during disassembly and assembly resulted in damage to the CRI14 fuel injector.
- 2) The fuel used for the vehicle does not meet the standard, causing damage to the CRI14 fuel injector, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- 3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. All above reasons can cause damage to the CRI14 fuel injector.
- 4) The abrasion of the oil pump produces iron powder and aluminum powder enter the CRI14 Fuel injector



and cause damage to the CRI14 fuel injector.

- 5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the CRI14 fuel injector and causing damage to the CRI14 fuel injector.
- 6) The CRI14 fuel injector is damaged due to replacement or adjustment of the relevant parts of the CRI14 fuel injector. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the CRI14 fuel injector fails to meet the original standard.
- 7) The engine is overheated and overloaded for a long time working results in damage to the CRI14 fuel injector.
- 8) The CRI14 fuel injector will be damaged naturally at the end of its working life.
- 9) The CRI14 fuel injector is magnetized (CRI14 fuel injector parts' magnetic exceeded) causing the CRI14 fuel injector to not work properly.

Before replacing the CRI14 fuel injector, please check the engine parts carefully according to the engine maintenance manual to avoid the CRI14 fuel injector being damaged again after replacement.

2.6. 0445110943 CRI14 Fuel Injector Storage Standard

1) Choose a Suitable Storage Place

The warehouse and cargo yard where the CRI14 fuel injector is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkali, salts and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

2) Strict Requirements of Warehousing

Strict inspections should be carried out when the CRI14 fuel injectors are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged CRI14 fuel injectors must be protected from damage.

3) Keep The Warehouse Dry And Preventing Moisture

The relative humidity is usually below 70% for the CRI14 fuel injectors placed in the room, and the corrosion of the CRI14 fuel injectors is significantly reduced.

CRI14 fuel injectors must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

4) Stack Properly

After the CRI14 fuel injector is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the CRI14 fuel injector from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse.

If the CRI14 fuel injector package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

A It is forbidden to leave the CRI14 fuel injector exposed in the air for a long time.



It is forbidden to store acids, alkalis, salts and other substances together with the CRI14 fuel injector.

A The unpacked CRI14 fuel injector must be rust-proof during secondary storage.

2.7. 0445110943 CRI14 Fuel Injector Technical Support Obtaining Methods

- 1) CRI14 Fuel Injector Technical Data: <u>https://www.crinjectors.com/download/</u>
- 2) CRI14 Fuel Injector Videos: <u>https://www.crinjectors.com/videos/</u>
- 3) CRI14 Fuel Injector Encyclopedia: <u>https://www.crinjectors.com/category/news/encyclopedia/</u>
- 4) CRI14 Fuel Injector Information Query Software:

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit <u>http://shumatt.com</u> to get the download and installation tutorial.

5) YouTube:

Visit <u>https://www.youtube.com/channel/UCByvYBx7VjV_mAfxh_Hu-aw</u> to get the technical videos, stay tuned for more information.

3. 0445110943 CRI14 Fuel Injector Purchase and Delivery

3.1. 0445110943 CRI14 Fuel Injector Purchase Payment Term Payment Terms: T/T, PayPal, Alipay, WeChat

A Please contact our salesmen for specific payment information.

3.2. 0445110943 CRI14 Fuel Injector Main Sales Markets

CRI14 Fuel Injector Main Sales Markets: Asia, Europe, North America, South America, Africa etc.

3.3. 0445110943 CRI14 Fuel Injector Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. 0445110943 CRI14 Fuel Injector Shipping Ways

Destination in China Areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations Out of China's Areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. 0445110943 CRI14 Fuel Injector Lead time

Lead Time: Send out within 3 - 7 working days after receiving payment (Except for special products and special cases).

3.6. 0445110943 CRI14 Fuel Injector Logistics Time for Destination Out of China's Areas

DHL Logistics Time :

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country ofEstimatedDestinationArrival Time	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
--	---------------------------	------------------------	---------------------------



Japan	3 Days	OPUKECTORS	5-7Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days		/		1

A The logistics time is for reference only and is subject to the actual arrival.

3.7. 0445110943 CRI14 Fuel Injector Packing

Domestic Express Packaging: Usually wrapped in waterproof scotch tape. **International Express Packaging:** Wrapped with waterproof yellow tape after wrapping the black protective film.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, also, the products can be packaged according to customers' requirements.

A The packing tray is made of plastic and can be recycled.

A Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.



NO.	1		2		3	
						CRINJECTORS
						CD
						CRINJECTORS
Websi	te : www.crinject	ors.com © 202	24 Shenzhen Shu	matt Technology	Co., Ltd	



Image			
Name	Domestic Express Packaging	International Express Packaging	Pallet Shipping
Description	Wrapped by transparent tape	Wrapped with yellow tape after wrapping black protective film	Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

4. Company Information



13 / 15

IECTORS CF



• Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

Shenzhen Office: Exit C, Qiao Touxi Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

✔ After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: <u>1.8.0445110943 CRI14 Fuel Injector Warranty Instructions</u>)

4.2. Contact Information

DR	Name	WeChat/ WhatsApp	Email	то
	Ruby	+86-13410541523	hison@shumatt.com	

5. Copyright Statement

Without written authorization from Shenzhen Shumatt Technology Co., Ltd, no media or individual may use the content in "0445110943 CRI14 Fuel Injector Technical Data" for commercial purposes (including but not limited to modifying, republishing, copying, intercepting, reproducing, and disseminating any part of this work), otherwise it will be deemed as infringement. Any media or individual who commits the above-mentioned infringement must immediately stop the behavior and bear full responsibility for all adverse consequences caused thereby. Shenzhen Shumatt Technology Co., Ltd. reserves the right to pursue its economic and legal responsibilities in accordance with the property rights law and relevant laws and regulations.

If there is any question, please contact us via hison@shumatt.com.

